PR 3

PR 2

PR 1

- + + - - +

1 2 3 4 5 6

JACK FRONT VIEW

Rear Panel Jack on Matrix

PR 3

PR 2

PR 1

- + + - - +

1 2 3 4 5 6

PLUG TOP VIEW

Cable Plug

PIN 1 = DATA -

PIN 2 = AUDIO OUT FROM MATRIX +

PIN 3 = AUDIO IN TO MATRIX +

PIN 4 = AUDIO IN TO MATRIX -

PIN 5 = AUDIO OUT FROM MATRIX -

PIN 6 = DATA +

PAIR 1 = AUDIO RECEIVE (TO MATRIX)

PAIR 2 = AUDIO SEND (FROM MATRIX)

PAIR 3 = DATA

PAIRS MUST BE TWISTED.

STATION CABLE IS PIN TO PIN.

ADAM 3 RJ-11 Connectors
BRAND 4/12/05